## AR Platform Troubleshooting chart

A compilation by: www.ednutter.ws

## Failure of magazine to lock in weapon

Problem	Solution	Source
Defective or damaged magazine	Replace magazine	LEAC
Not enough spring tension	Adjust magazine catch tension or replace magazine catch spring	LEAC
Worn or broken Magazine catch	Replace	TM-9
Dirty or corroded magazine catch	Disassemble and clean	TM-9
Defective magazine catch spring	Replace	TM-9

## Failure to feed or go into battery

Problem	Solution	Source
Defective ammunition	Use new US factory made commercial or mil spec brass cased ammunition. Check for damaged cases	LEAC
Defective magazine	replace	LEAC
Ejector sticking	Clean or replace ejector or spring	LEAC
Dirty chamber	Clean chamber with chamber brush and cleaning solution. Wipe dry and inspect for debris or damage	LEAC
Debris in bolt lug locking area	Clean and inspect locking area. Check for lodged primer	LEAC
Bent gas tube	Replace gas tube and insure proper alignment	LEAC
Worn or defective carrier key	Replace carrier key. Reinstall screws and torque to 35-40 inch pounds. Double stake the screws	LEAC
Defective gas rings	Replace gas rings	LEAC
Live round stuck in chamber	Point firearm in safe direction. Put selector in safe position. Separate the upper and lower receivers. Remove bolt carrier group. Remove stuck round with live round extraction tool.	LEAC
Fired case stuck in chamber	Use a cleaning rod inserted from the muzzle end to gently tap out the	LEAC

	spent cast from the chamber.	
Case separation	Remove remainder of case from chamber with a case extractor	LEAC
Magazine catch spring weak or broken	Replace	TM-9
Magazine catch broken or defective	Replace	TM-9
Short recoil		TM-9

### Failure to chamber

Problem	Solution	Source
Obstruction in bore/chamber	- Remove obstruction - Rebarrel	TM-9

#### Double Feed

Problem	Solution	Source
Defective Magazine	Replace	LEAC
Weak extractor spring/insert	Replace	LEAC
Defective Extractor	Replace	LEAC
Broken or sticking ejector	Clean or replace ejector and spring	LEAC
Dirty Chamber	Inspect chamber and clean with chamber brush and bore cleaner	LEAC

## Firing out of battery

Problem	Solution	Source
Broken Cam pin		AR-15

#### Failure to Lock

Problem	Solution	Source
Damaged bolt carrier key	-Repair -Replace - Check alignment	TM-9
Loose screws on bolt carrier key	<ul> <li>Disassemble and repair</li> <li>Reassemble using new screws</li> </ul>	TM-9
Bent gas tube	<ul> <li>- Adjust by bending in area of handguards</li> <li>- Replace gas tube</li> <li>- Check alignment</li> </ul>	TM-9

### Failure to Fire

Problem	Solution	Source
Broken hammer	Replace	TM-9
Weak or broken hammer spring	Replace	TM-9
Hammer spring improperly assembled	Reassemble	TM-9
Selector lever frozen on safe position	- Disassemble - Clean	TM-9
Broken firing pin or firing pin does not meet protrusion requirement	Replace	TM-9
Damaged, dirty, or corroded spring and detent	Clean or replace	TM-9

## Light Hammer Strike

Problem	Solution	Source
Improper hammer spring installation	Reinstall correctly	LEAC
Damaged or weak hammer spring	Replace	LEAC

## Trigger Failure

Problem	Solution	Source
Multiple rounds per trigger pull	Replace weak disconnector spring and/or worn disconnector	LEAC
Semi-auto fires full-auto	Missing or broken disconnector spring. Replace spring	LEAC
Hard to pull or failure to pull	Inspect for broken or loose parts. Inspect for debris (including blown primers) in lower receiver. Remove debris and clean as necessary.	LEAC

### Failure to unlock

Problem	Solution	Source
Burred locking lugs on bolt assembly	Remove burrs	TM-9
Burred locking lugs on barrel extension	Remove burrs	TM-9
Short recoil		TM-9
Broken bolt assembly	Replace	TM-9

#### Failure to extract

Problem	Solution	Source
Badly pitted chamber	Replace barrel	TM-9

## Failure to eject

Problem	Solution	Source
Short recoil		TM-9

#### Failure to cock

Problem	Solution	Source
Worn or broken trigger nose or trigger spring	Replace spring or trigger	TM-9
Worn or broken hammer trigger notch	Replace hammer	TM-9
Worn or broken hammer disconnector hook	Replace hammer	TM-9
Worn or broken hammer automatic sear hook	Replace hammer	TM-9
Worn or broken disconnector hook	Replace disconnector	TM-9
Weak, broken or missing trigger spring	Replace spring	TM-9
Worn, broken or missing automatic sear	Replace automatic sear	TM-9
Weak or broken automatic sear spring	Replace Automatic Sear spring	TM-9
Automatic sear spring incorrectly assembled in receiver	Remove automatic sear assembly and install correctly	TM-9

### **Short Recoil**

Problem	Solution	Source
Defective Ammunition	Use new US factory made commercial or mil spec brass cased ammunition. Check for damaged case	LEAC
Dirty chamber	Clean chamber with chamber brush and cleaning solution, wipe dry and inspect for debris or damage	LEAC
Loose carrier key	Remove bolt carrier group, clean all parts, remove any oil under the carrier key. Reinstall screws and torque to 35-40 inch pounds. Double stake the screws	LEAC
Broken carrier key screws	Replace	LEAC
Worn carrier key	Replace	LEAC
Bent or worn gas rings	Replace	LEAC
Bent or worn gas tube	Realign gas tube or replace gas tube	LEAC
Gas port in barrel and port in gas block or front sight misaligned	Carefully expand the gas block/front sight hole with a Dremel tool	LEAC
Improper gas port size	Check gas port size, carefully drill larger if undersized	LEAC
Bent lips on magazine causing bolt drag	Replace magazine	LEAC
Solid A2 buttstock screw	Replace with proper vented screw	LEAC

Improper buffer or spring	<ul> <li>Replace with proper</li> <li>buffer or spring</li> <li>Rifle spring has 42 coils</li> <li>CAR spring has 37 coils</li> </ul>	LEAC
Misalignment between gas port in barrel and port in front sight housing causing restricted gas flow	Open the port in the front sight housing with a dremel tool and a very small grinding bit. Drift port hole in the direction of the barrel hole to create a channel for the gas	LEAC
Improper gap, space, or worn, missing or broken bolt rings	Replace bolt rings and stagger gaps	TM-9
Broken or bent gas tube	Adjust by bending in area of handguards or replace gas tube	TM-9
Gas tube spring pin missing from front sight	Replace spring pin	TM-9
Partially plugged gas system because of carbon buildup in the gas tube	Replace gas tube	TM-9
Carbon buildup in barrel gas port	Remove carbon buildup	TM-9

## Weapon cannot be zeroed

Solution	Source
Replace barrel	TM-9
Align barrel and upper receiver	TM-9
Disassemble, clean, lubricate	TM-9
	Replace barrel  Align barrel and upper receiver  Disassemble, clean,

## **Decreasing Accuracy**

Problem	Solution	Source
Excessive chamber throat wear	Check throat erosion with a Throat Erosion Gauge. Replace barrel if necessary	LEAC

## Failure to cycle with selector set on AUTO

Problem	Solution	Source
Broken automatic sear or spring	Replace automatic sear assembly	TM-9
Faulty selector lever	Replace	TM-9
Short Recoil		TM-9

## Full Auto cycles too fast

Problem	Solution	Source
Fast cycle	Use heavier buffer	LEAC

# Fires when trigger is released with selector lever on SEMI, or fires two or more rounds in SEMI selector position (Doubling)

Problem	Solution	Source
Defective disconnector	Replace	TM-9
Worn or broken hammer trigger notch or worn or broken hammer disconnector notch	Replace hammer	TM-9
Worn or broken trigger nose	Replace trigger	TM-9
Worn trigger or hammer pin hole	Gage trigger and hammer pin holes	TM-9

### Fires with selector lever on safe

Problem	Solution	Source
Defective selector lever	Replace	TM-9
Worn or broken trigger – rear portion	Replace	TM-9

## Bolt fails to lock to rear after firing last round

Problem	Solution	Source
Defective magazine	Replace magazine. Destroy damaged magazine.	LEAC
Broken bolt catch	Replace	LEAC
Missing bolt catch plunger	Replace/install bolt catch plunger	LEAC
Broken or worn bolt catch spring	Replace spring	LEAC
Restricted movement of bolt catch	Disassemble and clean	TM-9

#### **Excessive Pressure**

Problem	Solution	Source
Defective ammunition	Use new US factory made commercial or mil spec brass cased ammunition. Check for damaged case	LEAC
Improper gas port – too large	Replace barrel	LEAC
Short or excessive headspace	Option 1. New bolt. Check headspace with new bolt to see if it cures headspace issue.  Option 2. Replace barrel. Check headspace to verify.	LEAC

Problem	Solution	Source

Problem	Solution	Source

Problem	Solution	Source

Problem	Solution	Source

Problem	Solution	Source

#### Works Cited

"AR-15 firing out of battery - The Firing Line Forums." *The Firing Line Forums RSS*, thefiringline.com/forums/showthread.php?t=470494.

Campbell, R.K. "A primer on AR-15 problems: despite decades-old war stories, AR-15 rifles are rugged and reliable. However, not all ARs are created equal and even the best can have their moments." American Gunsmith, Mar. 2011, p. 15+.

Carlos, Joe. "AR-15 diagnostics." American Gunsmith, July 2016, p. 7.

FM3-22.9 Rifle Marksmanship M16/M4 series Weapons. Department of the Army, Web. 7 Nov 2017.

<a href="http://usacac.army.mil/sites/default/files/misc/doctrine/CDG/cdg\_resources/manuals/fm/fm3">http://usacac.army.mil/sites/default/files/misc/doctrine/CDG/cdg\_resources/manuals/fm/fm3</a> 22x9.pdf>.

Hänks D. A. The Workbench AR-15 Project: a Step-by-Step Guide to Building Your Own Legal AR-15 without Paperwork. Paladin Press, 2004

LEAC AR15 M16 M4A1 Rifles and Carbines. American Gunsmith Institute.

Long, Duncan. The AR-15/M16: a Practical Guide. Paladin, 2010.

Long, Duncan. *The Complete AR-15/M16 Sourcebook: What Every Shooter Needs to Know.* Paladin, 2010.

Muramatsu, Kevin. *Gun Digest Guide to Customizing Your Ar-15*. F&w Publications Inc, 2014.

Sweeney, Patrick. Gun Digest Book of the Ar-15. Vol. 4, Krause Publications, 2012.

Sweeney, Patrick. *Gunsmithing the AR-15: How to Maintain, Repair, Accessorize*. Vol. 1, Gun Digest Books, 2010.

Sweeney, Patrick. Gunsmithing the AR-15: the Bench Manual. Gun Digest Books, 2016.

Sweeney, Patrick. Gunsmithing the AR-15. Field Stripping, Detailed Disassembly, Step-by-Step Instructions. Vol. 2, Gun Digest Books, 2014.

*TM9-1005-249-23*. Department of the Army, ia601409.us.archive.org/16/items/ArmyTechnicalManualforM16Rifle-Tm9-1005-249-23p/Manual-Tm9-1005-249-23p.pdf.

Wood, Dennis A. "Maintenance and troubleshooting of AR-15-type rifles: whether built by Colt, another quality gunmaker, or assembled on the owner's kitchen table from parts, some simple procedures and helpful aftermarket parts can keep the AR firing smoothly." *American Gunsmith*, Dec. 2007, p. 10+.

Zediker, Glen D. "Troubleshooting the AR-15." Guns Magazine.Com, gunsmagazine.com/troubleshooting-the-ar-15/.